

COMBINATION LOCK M224, 4-DIGITS MASTER KEY AND CODE FINDER

- high quality furniture fittings



Application:
For drawers and cabinets.

Accessories for one set:
1 lock body
72,8 x 42,8 x 25,3 mm L/W/D
1 cam plate c.e: 32 mm (steel)
1 spring mounting clip (steel)

Specifications:
ABS lock housing
Cylinder inner core made of zamak
4 digits fom 0-9
90° turn - right hand
With master key and code finder

Item No.: # 14.08.259

Application for metal or wooden panel by
optional back plates.


For metal Item No.: # 14.08.247

For wood Item No.: # 14.08.248

Master key Item No.: # 14.08.250

180° turn - right hand:

Item No.: # 14.08.258



SETTING YOUR PERSONAL COMBINATION

Your new resettable combination Cabinet Lock is
preset at 0-0-0-0. (Even though dials may appear in other
numbers).

To reset the combination:

Step 1

Leave the dials at preset combination 0-0-0-0.

Step 2

Turn the button clockwise 90° / 180° to the open position.

Step 3

Push the lever on the back of lock from A to B position. Set
the dials to your own desired combination.

Step 4

Push the lever back to A position, your lock is now ready to
open at your own personal combination.




Decode function :

Press down the decoding panel, keep holding it.
Rotate the dial till the decoding panel sink.
Repeat the same process for all dials, you will get the
numbers. (ex:6159)
Minus 3, it is the preset combination.(ex:3826)



Remark

Master key function only for an emergency
access.



For metal Item No.: # 14.08.247



For wood Item No.: # 14.08.248